



# SEAM SEALER REMOVAL

## STANDARD OPERATING PROCEDURE

### 1 PREP



Clean with **SEM Solve** or **XXX Universal Surface Cleaner**.

Wipe clean in one direction with a clean, lint-free towel.

### 2

#### METHOD #1



Remove seam sealer using the **QLock Strip It Wheel**.

### 3

#### METHOD #2



Remove seam sealer using the **Course Grit File Belt** attached to file belt sander.

### PRODUCT LIST



### PREP

Part	Product	Size
38371	SEM Solve	Gallon
38373	SEM Solve	20 oz. Aerosol
38374	SEM Solve	Square Quart
77771	XXX Universal Surface Cleaner	Gallon
77774	XXX Universal Surface Cleaner	Quart



### ABRASIVES

Part	Product	Size
SA40020	QLock Strip It Wheel	4"
SA120CG	Course Grit File Belt	1/2" x 18"
SA380CG	Course Grit File Belt	3/8" x 13"

### LEARN MORE AT

[www.semproducts.com](http://www.semproducts.com)

### SEM Products

Rock Hill, SC 29730

Tech Support: 1-800-831-1122

Customer Care: 1-866-327-7829

[semproducts.com](http://semproducts.com)



CHECK LOCAL VOC REGULATIONS TO ENSURE COMPLIANCE OF ALL PRODUCTS IN YOUR AREA. ALWAYS WEAR OSHA REQUIRED (PPE) PERSONAL PROTECTION EQUIPMENT TO ENSURE YOUR SAFETY.