

**1 INSTALL ADAPTER**



Review crossover sheet to determine the correct adapter for your spray gun.  
Insert adapter into spray gun and tighten.

**2 INSTALL LINER**



Insert liner into hard cup. Make sure to align vent tabs on liner with slots in bottom of hard cup.  
Turn liner clockwise to lock in place.  
Fill cup with desired material.

**3 ATTACH LID**



Firmly press lid onto assembled cup and liner.  
Lock down all four lid tabs.

**4 ATTACH CUP TO SPRAY GUN**



Press adapter onto assembled cup.  
Align locking tabs on adapter to corresponding tabs on lid.  
Turn clockwise until lid locks in place.  
**!** Locking only takes a quarter turn.

**5 OPEN/CLOSE RUBBER VENT**



Open rubber vent in liner for most spray applications.  
For inverted spray applications, close vent and allow liner to collapse.  
**!** Don't forget to close vent for liquids storage or when inverting.

**WATCH & LEARN**



Watch the training video and download additional literature at:  
[semproducts.com/vcs-video](http://semproducts.com/vcs-video)

**PRODUCT LIST**



**ADAPTERS**

Part	Product	Quantity
92501	Adapter 1	10 per case
92510	Adapter 10	10 per case
92511	Adapter 11	10 per case
92512	Adapter 12	10 per case
92513	Adapter 13	10 per case
92520	Adapter 20	10 per case
92521	Adapter 21	10 per case
92530	Adapter 30	10 per case
92540	Adapter 40	10 per case

Review crossover sheet to determine the correct adapter for your spray gun.



**HARD CUPS**

Part	Product	Quantity
92130	32 oz. Hard Cup w/ratios	20 per case
92132	32 oz. Blank Hard Cup	20 per case
92110	22 oz. Hard Cup w/ratios	20 per case
92112	22 oz. Blank Hard Cup	20 per case
92120	13 oz. Hard Cup w/ratios	20 per case
92122	13 oz. Blank Hard Cup	20 per case



**LINERS**

Part	Product	Quantity
92200	32 oz. Liner	200 per case
92210	22 oz. Liner	200 per case
92220	13 oz. Liner	200 per case



**LIDS**

Part	Product	Quantity
92300	Lid with 125 Micron Filter & Cap	200 Lids & 100 Caps per case

**SEM Products, Inc.**  
Rock Hill, SC  
Tech Support: 1-800-831-1122  
Customer Care: 1-866-327-7829  
[semproducts.com](http://semproducts.com)